


MyCNC Pulse Width Setup

- In myCNC software, navigate to **Settings**
- Open the **Hardware** tab
- Open the **Common Hardware Settings** tab. The following GUI will be presented:



- Select the appropriate **Pulse Width**

Selecting the Appropriate Pulse Width for your motor

A common procedure required for proper motor operation is selecting the appropriate pulse width for the signal going from the controller to the step/servo motor on the CNC machine. The pulse impulses sent from the controller to the motor have a certain width (as seen below), that cannot be too large due to the signal overlap that would occur otherwise because of each individual signal interfering with the next one. However, as seen in the following instructions from Panasonic's MINAS A5-series AC Servo Motor & Driver, the pulses also have to have a minimum width for the machine to register the signal, for example, 0.25 μ s for t1 of the 4 Mpps input and 2.5 μ s for t1 of the 500 kpps input:

3

Connection


1. Outline of mode

Position Control Mode

Outline

You can perform position control based on the positional command (pulse train) from the host controller.

This section describes the fundamental setup to be used for the position control.



Function

(1) Process of command pulse input

The positional commands of the following 3 types (pulse train) are available.

- 2-phase pulse
- Positive direction pulse/negative direction pulse
- Pulse train + sign

Set the pulse configuration and pulse counting method based on the specification and configuration of installation of the host controller.

The input terminals can accommodate the following 2 systems.

- Input 1 "PULSH1, PULSH2, SIGNH1, SIGNH2" line receiver input (4 Mpps)
- Input 2 "PULS1, PULS2, SIGN1, SIGN2" photocoupler input (500 kpps)

Caution

For line driver output, "Input 2" can also be used without changing the allowable input frequency.

• Relevant parameters

Parameter No.	Title	Range	Function
Pr0.05	Selection of command pulse input	0 to 1	You can select either the photo-coupler input or the exclusive input for line driver as the command pulse input.
Pr0.06	Command pulse rotational direction setup	0 to 1	Sets the counting direction when command pulse is input.
Pr0.07	Command pulse input mode setup	0 to 3	Sets the counting method when command pulse is input.













Note

For details of these parameters, refer to P.4-6 and 7 "Details of parameter".

4. Inputs and outputs on connector X4

Input Signal and Pin No.

• Input format command pulse

Pr0.06 setup value (Command pulse rotational direction setup)	Pr0.07 setup value (Command pulse input mode setup)	Command pulse format	Signal title	Positive direction command	Negative direction command
0	0 or 2	90° phase difference 2-phase pulse (A + B-phase)	PULS SIGN	 B-phase advances to A by 90°.	 B-phase delays from A by 90°.
	1	Positive direction pulse train + Negative direction pulse train	PULS SIGN		
	3	pulse train + Signal	PULS SIGN	 "H"	 "L"
1	0 or 2	90° phase difference 2-phase pulse (A + B-phase)	PULS SIGN	 B-phase delays from A by 90°.	 B-phase advances to A by 90°.
	1	Positive direction pulse train + Negative direction pulse train	PULS SIGN		
	3	pulse train + Signal	PULS SIGN	 "L"	 "H"

- PULS and SIGN represents the outputs of pulse train in put circuit. Refer to the fig. of P.3-30, "Input Circuit".
- In case of negative direction pulse train + positive direction pulse train and pulse train + sign, pulse train will be captured at the rising edge.
- In case of 2-phase pulse, pulse train will be captured at each edge.

• Permissible max. input frequency, and min. necessary time width of command pulse input signal.

Input I/F of PULS/SIGN signal		Permissible max. input frequency	Min. necessary time width (μs)					
			t ₁	t ₂	t ₃	t ₄	t ₅	t ₆
Pulse train interface exclusive to line driver		4Mpps	0.25	0.125	0.125	0.125	0.125	0.125
Pulse train interface	Line driver interface	500kpps	2	1	1	1	1	1
	Open collector interface	200kpps	5	2.5	2.5	2.5	2.5	2.5

As another example, the Yaskawa's E-7-Series AC Servo Drive also imposes a similar constraint on the minimum widths:

6.6 Position Control

6.6.1 Basic Settings for Position Control

6.6.1

Basic Settings for Position Control

This section describes the reference pulse forms and input filters.

Reference Pulse Forms

To perform speed control, you must specify how the reference is input from the host controller (i.e., the reference pulse form). You set the reference pulse form in Pn200 (Position Control Reference Form Selections).

Parameter	Reference Pulse Form	Input Pulse Multiplier	Forward Reference	Reverse Reference
n.0000 (default setting)	Sign and pulse train, positive logic.	—		
n.0001	CW and CCW pulse trains, positive logic	—		
n.0002	90° phase-differential pulses	x1		
n.0003		x2		
n.0004	90° phase-differential pulses	x4		
n.0005		Sign and pulse train, negative logic.	—	
n.0006	CW and CCW pulse trains, negative logic	—		

Selecting an Input Filter

Parameter	Meaning	When Enabled	Classification
n.0000 (default setting)	Use the reference input filter 1 for a line-driver signal. (1 Mpps max.)	After restart	Setup
n.1000	Use the reference input filter for an open-collector signal. (200 kpps max.)		
n.2000	Use reference input filter 2 for a line-driver signal. (1 to 4 Mpps)		

Application Functions

6

6.6 Position Control

6.6.1 Basic Settings for Position Control

Electrical Specifications for Pulse Train Reference

The following table describes the forms for pulse train references.

Pulse Train Reference Form	Electrical Specifications	Remarks
Sign and pulse train (SIGN and PLUS signals) Maximum reference frequency: 4 Mpps (maximum reference frequency for open-collector output: 200 kpps)		

value will always be equal or higher than the minimum allowable **[seconds / step]** value of the motor due to selecting a lower **[steps / revolution]** value in the previous steps.

- For example, if the **[revolutions / second]** value was equal to 16 revolutions/second and the stepper driver **[steps / revolution]** value was equal to 6400 steps/revolution, the actual **[seconds / step]** value of the motor will be equal to 9.8 µs/step.
- The value for the **Pulse Width** in myCNC software must be equal or higher than the actual **[seconds / step]** value of the motor.
 - For example, if the **[seconds / step]** value was equal to 9.8 µs/step, and an ET6 or an ET7 board was used, 12 µs would be selected from the chart in the **Common Hardware Settings** tab as it is the closest value that's higher than 9.8 µs.

	0	1	2	3	4	5	6	7
ET1	0.32 us	0.64 us	0.96 us	1.28 us	1.60 us	1.92 us	2.24 us	5.0 us
ET3	0.16 us	0.32 us	0.48 us	0.64 us	0.8 us	0.96 us	1.12 us	2.5 us
ET6, ET7	0.13 us	0.25 us	0.50 us	1.0 us	2.0 us	4.0 us	8.0 us	12 us
ET10	0.13 us	0.25 us	0.50 us	1.0 us	2.0 us	4.0 us	8.0 us	10 us

- The 12 µs corresponds to Setting 7 in the chart, thus the **Pulse width** value should be set to 7.
 - NOTE: The first value in the **Pulse Width** line refers to the first four axes of the controller (for example, the horizontal X and Y axes), while the second value refers to the other two axes of the controller (for example, the vertical Z axis). These values are set to be different if the controller used on the vertical axis is separate from that used on the horizontal, and are left the same if only one controller is used.

Pulse width

- The pulse width setup is now complete.

From:

<http://docs.pv-automation.com/> - myCNC Online Documentation

Permanent link:

http://docs.pv-automation.com/mycnc/mycnc_pulse_width_setup?rev=1555522287

Last update: 2019/04/17 13:31

