

# 3D Height Mapping


## Related articles:

- [Getting a Height Map](#)

**ATTENTION:** Height mapping is currently in beta testing.


Height mapping allows to correct the G-code program for abnormalities and slight surface variations of the working material by mapping out the height map of the working material prior to beginning the cutting job. This function is extremely useful when dealing with a working surface which might be oriented imperfectly or may have some abnormalities to it, as well as programs which require a high degree of precision.

The function is currently being tested for the X1366M, X1366M4 and X1366M6 profiles. Below is an example of the height mapping process in its current beta testing form:




In order to perform the height mapping procedure, do the following:

- Open the file that you will want to correct for the material variations



- After opening the file, head to the Map tab on the main screen of myCNC software



- Select your Segment Length and your XY Grid. Increasing segment length and XY grid will result in less probe points being taken.

The screenshot shows a CNC control interface with a 3D height map of a circuit board. The 'Map' section displays a grid of coordinates:

X	Y	Z
70.000	76.000	2.000
117.000	148.000	-10.000
59.000	148.000	4.000
137.000	31.000	20.000
137.000	207.000	-3.000
100.000	102.000	5.000
86.000	120.000	15.000

The 'Mill' section settings are:

- Segment Length, [mm]: 10.0
- Measure Grid X\*Y, [mm]: 50.0 \* 50.0
- Probe Speed: 50.0
- Slow Speed: 30.0
- Probe Lift Height: 2.0
- Bounce Back: 2.0

- Select your probe speeds. The probe speed is the speed with which the probe will be moving down from the start of the downward movement to the first contact with the surface. The slow speed is the speed on the rebound, allowing for a more precise measurement of the z-height position on second contact.

The screenshot shows the same CNC control interface as above, but with different settings highlighted in the 'Mill' section:

- Probe Speed: 50.0
- Slow Speed: 30.0

The 'Map' section coordinates are identical to the previous screenshot.

- Select your Lift Height and Bounce Back settings. The Lift Height specifies the z-axis height to which the probe will be lifted between different probing points (safe height). Note that this height is absolute, not relative, so it will raise it TO the position specified in this field in program coordinates, NOT raise the probe BY that amount. The Bounce Back setting specifies the distance the probe retracts after first coming into contact with the working material surface


before beginning to move down again.

The screenshot displays a CNC control interface with the following components:

- Top Panel:** Includes icons for file operations (Load, DIF, NEW), zoom (in, out, reset), and axis selection (L, B, A).
- Left Panel:** Shows coordinate system axes (Z, Y, X) and a 'P' button.
- Main Display:** A dark blue area showing a green wireframe of a part. Dimensions are indicated as 132.191 and 193.433.
- Right Panel:** Displays G54 coordinates for X, Y, Z, and A axes. Values include 98.000, 850.230, 55.197, 1158.924, 3.688, -1970.384, and 0.00.
- Bottom Left Panel:** Contains speed controls (Jog over speed, Over Speed) and Spindle Speed (24000 rpm). Tool settings show Tool Length (2.000 mm) and Z correction (0.000 mm).
- Bottom Center Panel:** A 'Map' section with options for 'Area' and 'Fill Area'. It lists parameters: Segment Length (10.0 mm), Measure Grid X\*Y (50.0 \* 50.0 mm), Probe Speed (50.0), Slow Speed (30.0), Probe Lift Height (2.0 mm), and Bounce Back (2.0 mm). The 'Probe Lift Height' and 'Bounce Back' values are highlighted with a red box.
- Bottom Right Panel:** A coordinate table with columns for X, Y, and Z.
- Bottom Far Right Panel:** Includes a 'STOP' button and navigation arrows.


X	Y	Z
70.000	76.000	2.000
117.000	148.000	-10.000
59.000	148.000	4.000
137.000	31.000	20.000
137.000	207.000	-3.000
100.000	102.000	5.000
86.000	120.000	15.000

- Select whether you want the material to be probed in a Rectangular or a Fill Area pattern. Generally, either of these methods will give similar results:




- Press the Generate Map button. Note that in order for the map to position itself properly, the X and Y program coordinates must be at zero prior to the map generation step.







- After the file has been corrected for surface level imperfections, you can press the Run button again to begin the actual job.
- If you would like to add a manual measurement of a point or a set of points, you can do so by moving the machine to an arbitrary XY location and recording the height there using the Manual Height Probing button. This will add that XYZ point to the existing height array.



- If you would like to clear the existing generated map (for example, for the purposes of manually recording a set of points without data from the automatic measurements), you can do so using the Clear Map button.



- If you would like to save the existing map in order to apply it to a G-code file at a later point, you can do so using the Save Map button. The map will be saved in the folder specified in Settings > Config > Technology > Special Purpose > Height Map.



## Setting up the probing procedure (beta users)

The 3D height map .xml file for the X1366M-series profiles is currently available on request (beta testing as of October 2019). In order to set up the profile once you have received the file, do the

following:

- Head into `home/.config/myCNC/profiles/X1366M` (or `X1366M4/M6` if using those) and switch the old `x-bottab-left-mill.xml` for the new provided file.
- Head into `myCNC Settings > Config > PLC > Hardware PLC` and add the M180 procedure if it is not already present.
  - On recent software versions, it can be added by going into `PLC > Hardware PLC Templates`, selecting M180 (Double touch probing for Height Map) and clicking the Save PLC button in the lower right corner of the screen. After this, head back into `PLC > Hardware PLC` and press the Save All, Build All and Send buttons to begin the PLC disk reflashing process.
  - On older software versions, add the M180 procedure by manually creating an M180 file in the Hardware PLC section and pasting the following code:

```
#include pins.h

do_probe()
{
  g0moveA(0,4,0-10000); //100 mm down
  timer=200; do{timer--;}while(timer>0); //wait till motion started
  do{
    code=gvarget(6060);
    if (code==0x4d)
      {
        gvarset(9121,1);
        timer=30;do{timer--;}while(timer>0);
        message=PLCCMD_MOTION_BREAK; timer=10;do{timer--;}while(timer>0);
        message=PLCCMD_MOTION_BREAK; timer=10;do{timer--;}while(timer>0);
        exit(99);
      };
    sens=portget(INPUT_PROBE);
    if (sens!=0)
      {
        code=1;
        message=PLCCMD_LINE_STOP;
        timer=10;do{timer--;}while(timer>0);
      };
  }while (code==0);
  do { code=gvarget(6060); }while(code!=0x4d); //wait till motion finished
};

do_rebound()
{
  //speed=gvarget(8254); //
  gvarset(7080,2000); //
  timer=20;do{timer--;}while(timer>0);
  bounce=gvarget(8256);
  g0moveA(0,4,bounce); //bounce
  timer=200; do{timer--;}while(timer>0); //wait till motion started
  do { code=gvarget(6060); }while(code!=0x4d); //wait till motion finished
};
```

```
do_lift()
{
  //speed=gvarset(8254); //
  gvarset(7080,2000); //
  timer=20;do{timer--;}while(timer>0);

  lift_height=gvarset(8257);
  g0moveA(1,4,lift_height); //Lift Height
  timer=200; do{timer--;}while(timer>0); //wait till motion started
  do { code=gvarset(6060); }while(code!=0x4d); //wait till motion finished
};

main()
{
  message=PLCCMD_TRIGGER4_OFF;
  timer=2;do{timer--;}while(timer>0);

  sens=portget(INPUT_PROBE);
  if (sens!=0)
  {
    gvarset(7080,2000); //1000mm/min
    timer=20;do{timer--;}while(timer>0);
    do_rebound();
  };

  sens=portget(INPUT_PROBE);
  if (sens==0)
  {
    speed=gvarset(8253); //Probe Speed
    gvarset(7080,speed); //
    timer=20;do{timer--;}while(timer>0);
    do_probe();
  };

  do_rebound();

  sens=portget(INPUT_PROBE);
  if (sens==0)
  {
    speed=gvarset(8254); //Slow Speed
    gvarset(7080,speed); //
    timer=20;do{timer--;}while(timer>0);
    do_probe();
  };

  gvarset(5730,0);
  timer=20;do{timer--;}while(timer>0);

  do_lift();
}
```

```
exit(99);  
};
```

- Note that the probe sensor number is defined in the INPUT\_PROBE field which is used in the M180 PLC procedure. This can be changed by going into Settings > Config > PLC > Hardware PLC > pins.h, and switching the default INPUT\_PROBE input number to the one used by your particular setup. After assigning a new probe number, do not forget to once again press the Save All, Build All and Send buttons to reflash the disk.

## Changelog

**2019-10-15:** Manual Height Probing and Clear Map buttons have been added. Manual Height Probing allows the user to take a height measurement in some arbitrary point on the working surface, while the Clear Map button allows to delete the current point array and start anew. Save and Open Map buttons should now be stable.

**2019-10-07:** Save and Open Map buttons are now operational (some stability issues might be present). The generated map point spread is now shown within the software.

**2019-10-04:** The Save and Open Map buttons do not work yet. These will allow the user to save the created map and to load a previous map to apply to the G-code file.

From:

<http://docs.pv-automation.com/> - **myCNC Online Documentation**

Permanent link:

[http://docs.pv-automation.com/mycnc/height\\_mapping](http://docs.pv-automation.com/mycnc/height_mapping)

Last update: **2024/03/22 14:12**

