

Load PLC from template

In order to load PLC from template, please use the instructions below:

1. Open **CNC Settings > Config > PLC > Hardware PLC**. You will be presented with the following screen:




2. Click on the **Open Templates** button on the **Hardware PLC** screen.



3. The following screen with the list of the current PLC Templates will pop up:




On this screen, you can see a number of different PLC template or templates along with their code and descriptions. Find the particular template that you want to load in, switch the checkmark to green, and click save.




```
NOTE: You can also choose to manually copy and paste the template code
into the Hardware PLC screen
```

4. Close the template popup screen and return to the **Hardware PLC** screen, then click the three buttons on the right of the screen to Save, Build All and Reflash Disk.



The PLC templates should now be loaded.

From:
http://docs.pv-automation.com/ - **myCNC Online Documentation**

Permanent link:
http://docs.pv-automation.com/plc/load_from_template?rev=1559314318

Last update: **2019/05/31 10:51**