


myCNC-ET9 main features in addition to the functionality present on the previous iterations of the board:

- Motor driver can be plugged into an auxiliary connector (outputs #17/#18)
- 2 PWM ports duplicated (PWM1, PWM2)
- Since the driver board is designed for 2 motors, therefore the ET9 has support for both

## Reflashing the ET9 board

Reflashing the ET9 board

To reflash the ET9 board, follow the instructions on reflashing the ET7 boards here, however make sure to select the **ET7-R4/R5/R6 (ET9)** option in the Select Board field.



Failure to select the correct revision version of the board will result in your board being non-operational. Please consult the myCNC support team prior to a reflash should you have any questions.

From:

<http://www.cnc42.com/> - **myCNC Online Documentation**

Permanent link:

[http://www.cnc42.com/mycnc/mycnc\\_et9](http://www.cnc42.com/mycnc/mycnc_et9)

Last update: **2026/04/17 10:09**

