
Teamviewer Reset Config

If you create disk (microSD card content) from image with preinstalled Teamviewer software it may have identical Teamviewer ID. If several computers with identical ID connected to Internet it might e a problem to connect to particular Computer via Teamviewer.


To solve this problem you need to reset Teamviewer configuration. Teamviewer with clear configuration will obtain from Teamviewer servers a new unique ID.

Below there is sequence to obtain new Teamviewer ID


- Open File Manager (Top left icon - “operator's Home”);
- find “/etc” folder;




- find there **teamviewer** folder and enter to it;



- There is the only file **global.conf**;
- Press right mouse button on it and select **Open as Administrator**;



- Remove all content of the file and **Save** the changes;



- Restart Teamviewer (press “Teamviewer STOP” icon, then “Teamviewer START”);



- Accept Teamviewer EULA and check if new ID is assigned

From:
http://docs.pv-automation.com/ - **myCNC Online Documentation**

Permanent link:
http://docs.pv-automation.com/mycnc/teamviewer_reset_config?rev=1511407929

Last update: **2017/11/22 22:32**