


Welcome to the myCNC Documentation site

This website contains the manuals and documentation for the myCNC control boards and myCNC software designed and developed by [Puruvesi Automation](#). The index for the site is located in the left sidebar. Below you can find the QuickStart section which is designed to introduce the user to the myCNC initial setup process, as well as some general controller and software information pages.




Welcome to myCNC Docs

Please consult the [QuickStart](#) page for machine setup instructions



Welcome to myCNC Docs

Visit our [Frequently Asked Questions](#) page to get started



Welcome to myCNC Docs

The Search bar is located in the top right corner of the screen



Welcome to myCNC Docs

Visit our [Forum](#) for all discussion related to myCNC controllers and CNC in general

Other Languages:

- Документация на русском

MyCNC Quick Start:

- Frequently Asked Questions
- Profile Screen Description
- Installing Ubuntu MATE 18.04 through LiveCD with preinstalled myCNC software
- Installing the myCNC Linux ISO on a Tinkerboard SBC
- General myCNC setup
 - Plasma setup (X1366P)
 - Oxy-fuel setup (X1366G)
 - Tangential Knife setup (X1366V)

- Setting up the homing procedure
- Setting up Axes and Pulses per Unit
- Network Setup
- Setting up the probe tool
- CNC Vision (Camera) Setup
- Start/Stop Setup
- Importing DXF files into myCNC

Controller information:

- myCNC-ET6 CNC controller
- myCNC-ET7 CNC controller
- myCNC-ET10 CNC controller
- myCNC-ET15 CNC controller

General Software information:

- MyCNC Configuration Dialogs
- PLC
- myCNC Software

Recently added/edited pages:

Page	Date	Comment
CNC Vision Setup	Feb 26, 2024	Added info on potential zero coefficient results
Global Variables	Feb 22, 2024	Added AxisPlus & Laser gvariables
CNC S-Variables (String Variables)	Dec 14, 2023	Added missing svariables
Global Variables	Dec 11, 2023	Added vars 8042-8060, 8010-8041
Working material edge detection	Dec 05, 2023	Article created
Debug messages via global variables 20000-20100	Dec 05, 2023	Article created
Laser Cutting	Dec 01, 2023	Info on homing and calibration
Frequently Asked Questions	Oct 30, 2023	Difference between axes and motor outputs
AnyDesk Reset Config	July 05, 2023	Article created
Firmware Reflash	July 05, 2023	Expanded the reflash screenshots
Dental Aligners in myCNC	Jan 09, 2023	Article created
Importing DXF files into myCNC	Dec 14, 2022	Added more info on dxf2-import
MyCNC Installation on Ubuntu	Nov 23, 2022	Ubuntu 22.04 LTS install

If you have any questions, or if you cannot find some information on this page, in the [Site Index](#), or through the Search function, please reach out to the [myCNC Support Team](#).

From:
<http://docs.pv-automation.com/> - **myCNC Online Documentation**

Permanent link:
<http://docs.pv-automation.com/mycnc>

Last update: **2024/02/26 14:53**



