

No Connection between myCNC controller and a Host computer

Choose your system for the host computer:

- * [Armbrian Linux for a Single Board Computer](#)
- * [Ubuntu Mate](#)
- * [Windows 7](#)

From:

<http://docs.pv-automation.com/> - **myCNC Online Documentation**

Permanent link:

http://docs.pv-automation.com/troubleshooting/no_connection

Last update: **2019/12/20 14:51**

