

File System Check

* Press **Ctrl+Alt+F1**

* Enter login name:

```
mycnc
```

press Enter

* Enter password:

```
operator
```

, press Enter

* Run File system check utility -

```
sudo fsck -y /dev/sda5
```

* Reboot computer

```
sudo reboot
```

, press Enter

From:

<http://docs.pv-automation.com/> - **myCNC Online Documentation**

Permanent link:

http://docs.pv-automation.com/troubleshooting/file_system_check

Last update: **2021/12/14 19:59**

