



Welcome to the myCNC Documentation site

This website contains the manuals and documentation for the myCNC control boards and myCNC software. The index for the site is located in the left sidebar. Below you can find the QuickStart section which is designed to introduce the user to the myCNC initial setup process, as well as some general controller and software information pages.



Welcome to myCNC Docs

Please consult the [QuickStart](#) page for machine setup instructions



The Search bar is located in the top right corner of the screen

MyCNC Quick Start:

- [Installing Ubuntu MATE 18.04 through LiveCD with preinstalled myCNC software](#)
- [Installing the myCNC Linux ISO on a Tinkerboard SBC](#)
- [myCNC control board setup](#)
- [Setting up the homing procedure](#)

- [Setting up Axes and Pulses per Unit](#)
- [Network Setup](#)
- [Setting up the probe tool](#)
- [CNC Vision \(Camera\) Setup](#)
- [Start/Stop Setup](#)
- [Tangential Knife Setup](#)
- [Oxy-fuel Setup](#)
- [Importing DXF files into myCNC](#)

Controller information:

- [myCNC-ET6 CNC controller](#)
- [myCNC-ET7 CNC controller](#)
- [myCNC-ET10 CNC controller](#)
- [myCNC-ET15 CNC controller](#)

General Software information:

- [MyCNC Configuration Dialogs](#)

If you have any questions, or if you cannot find some information on this page, in the [Site Index](#), or through the Search function, please reach out on the [myCNC Forum](#).

From:

<http://docs.pv-automation.com/> - **myCNC Online Documentation**

Permanent link:

<http://docs.pv-automation.com/mycnc?rev=1570218257>

Last update: **2019/10/04 15:44**

